

# WAKOL D 3200 SpaltTex VR

## Technical Information

### Area of application

Dispersion based adhesive with an integrated „zipper“ for laying textile flooring with fleece and latex foam backing on absorbent subfloors indoors. Flooring with fleece backing can be easily removed without residue.

### Special properties

- solvent-free\*
- suitable for chairs with castors
- with „zipper-effect“
- very low emission\*\*
- suitable over underfloor heating
- extremely low consumption

\* solvent-free according to the definition of the TRGS 610

\*\* classified according to criteria of the GEV in emicode EC1: very low emission

### Technical data

Raw material base:	acrylate dispersion
Cleaning agent:	water, before adhesive is drying
Method of application:	trowel notch size according to TKB B1 or B. The notch size depends on the back texture of the covering and must result in complete coating.
Consumption:	approx. 250-300 g/m <sup>2</sup> , depending on trowel notch size, subfloor and covering
Airing time:	approx. 5-10 minutes, depending on trowel notch size, subfloor and covering
Open time:	approx. 15 minutes
Storage temperature:	not below + 5°C, sensitive to frost
Storage time:	approx. 12 months at room temperature
Giscode:	D 1
Emicode acc. to GEV:	EC 1

## Subfloors

The subfloor and the room climate conditions must satisfy the requirements of DIN 18356. Subfloors must be absorbent, level, permanently dry, firm and free of cracks, dust, dirt and adhesion-inhibiting substances.

Apply corresponding WAKOL levelling compounds to non-absorbent and uneven subfloors. The technical information on the primers and levelling compounds must be heeded.

## Usage

Stir adhesive well before using. Using a notched trowel, apply uniformly on the subfloor, avoiding adhesive pools. Lay down covering following appropriate airing time and press well. Rub again after a short period.

If necessary, weigh down stubborn edges of covering until adhesive hardens.

For renovation just remove the flooring - the adhesive separates as a zipper. Treat rests of adhesives before the new laying as usually.

## Important

Do not use below +15°C. Warm up the floor covering and adhesive in time in cold weather.

We guarantee the uniform high quality of our products. All data is based on tests and many years of practical experience and refers to standardised conditions. The variety of materials used and the different construction site conditions, which lie beyond our control, preclude any claims based on this data. We therefore recommend making sufficient trials. Accompanying flooring manufacturer's instructions and the currently applicable codes must be observed. We gladly provide technical advice.

This Technical Information of 22.12.2004 supersedes all previous versions.