

WAKOL D 3240 Colleo

Technical Information

Area of application

For laying linoleum, textile flooring with fleece backing, latex foam backing, synthetic double backing or jute backing, woven textile flooring and needle fleece flooring as well as for PVC and CV flooring on absorbent subfloors indoors.

Special properties

- solvent-free*
- suitable for chairs with castors
- high strength
- very low emission**
- suitable over underfloor heating
- universal usable

* solvent-free according to the definition of the TRGS 610

** classified according to criteria of the GEV in emicode EC1: very low emission

Technical data

Raw material base:	acrylate dispersion
Cleaning agent:	fresh water, before adhesive is drying
Method of application:	trowel notch size according to TKB, A2 for PVC- and CV-flooring, A2 for textile flooring with latex foam backing, B1 or B2 for other textile flooring, B2 for needle fleece and B1 for linoleum. The notch size depends on the back texture of the covering and must result in complete coating.
Consumption:	approx. 330-600 g/m ² depending on trowel notch size, subfloor and covering
Airing time:	approx. 10 minutes, depending on trowel notch size, subfloor and covering
Open time:	approx. 15-20 minutes
Storage temperature:	not below +5°C, sensitive to frost
Storage time:	approx. 12 months at room temperature
Giscode:	D 1
Emicode acc. to GEV:	EC1

Subfloors

The subfloor and the climatic conditions of the room must meet the requirements of DIN 18365. Subfloors must be level, permanently dry, solid and free from cracks, dirt and adhesion inhibiting substances. Apply corresponding WAKOL levelling compounds to non-absorbent and uneven subfloors. The technical information on the primers and levelling compounds must be heeded.

Lay down PVC and CV on dense subfloors with contact bonding procedure only.

Usage

Stir adhesive well before using. Using a notched trowel, apply uniformly on the subfloor, avoiding adhesive pools. Lay down covering following appropriate airing time and press well. Rub again after a short period.

If necessary, weigh down stubborn edges of covering until adhesive hardens.

Important

Do not use below +15°C. Warm up the floor covering and adhesive in time in cold weather.

For laying textile floorings with PUR-foam backing as well as for Mipolam S and similar coverings use WAKOL D 941 or WAKOL D 3317. For gluing CV floorings with PVC-foam backing on V 100 chipboard use only WAKOL D 3317.

We guarantee the uniform high quality of our products. All data is based on tests and many years of practical experience and refers to standardised conditions. The variety of materials used and the different construction site conditions, which lie beyond our control, preclude any claims based on this data. We therefore recommend making sufficient trials. Accompanying flooring manufacturer's instructions and the currently applicable codes must be observed. We gladly provide technical advice.

This Technical Information of 17.02.2006 supersedes all previous versions.