

BUK Büffel Universal Kleber

Technical Information

Area of application

For laying floor coverings such as PVC- and textile flooring, for wall coverings such as ceramic tiles, under wall paper and cork wall coverings and for ceiling coverings such as hartfoam plates on absorbent subfloors indoors.

Special properties

- solvent free*
- suitable for chair castors
- suitable for new tiles on old tiles
- suitable for underfloor heating
- suitable for subfloor, wall and floor
- very low emission**

* solvent-free according to the definition of the TRGS 610

** classified according to criteria of the GEV in emicode EC1: very low emission

Technical data

Application: with trowel notch size according to A 2 for PVC flooring, B 2 for textiles flooring and wall covering, C 3 or C 2 for ceramic tiles

Consumption: approx. 350 g/m² with notched trowel TKB A2,
approx. 450 g/m² with notched trowel TKB B 2,
approx. 700-1400 g/m² with notched trowel TKB C 3, C 2

Subfloors

Concrete subfloors, like cement paving, calcium sulphate concrete (anhydrite screeds), cast asphalt and P4 to P7 chipboard.

Subfloors must be absorbent, level, permanently dry, firm and free of cracks, dust, dirt and adhesion-inhibiting substances.

For PVC laying, levelling compound must be applied on all subfloors with sufficient thickness (2 mm). Prime calcium sulphate concrete and cast asphalt for all laying with WAKOL D 3074 Primer Concentrate and apply WAKOL Z 615 Levelling Compound with a thickness of at least 2 mm.

Usage

Stir adhesive well before using. For laying in wall and floor areas apply adhesive with notched trowel evenly on the subfloor or subsurface. For PVC flooring use notched trowel TKB A2, for carpeting use notched trowel TKB B2. Avoid adhesive pools. Immediately fit flooring and press well. Rub stiff flooring again after approx. 20 minutes. If tiles are to be bonded to old, firmly bonded ceramic tiles, cover the cleaned old tiles with a thin layer of adhesive 1 - 2 days before laying. Then lay the new tiles as usual. Use notched trowel TKB C3 or TKB C2, depending on the backs of the tiles. Grouting of ceramic tiles on absorbent wall surfaces after 1 day, on non-absorbent surfaces and on subfloors at the earliest after 7 days. For laying ceiling panels, evenly apply adhesive with notched trowel TKB B2 on the undersides of the panels. Immediately position the panel and press down firmly. Clean tools with water before the adhesive dries.

Important

Do not use below + 15° C. During cold weather periods warm up floor covering and adhesive in due time.

We guarantee the uniform high quality of our products. All data is based on tests and many years of practical experience and refers to standardised conditions. The variety of materials used and the different construction site conditions, which lie beyond our control, preclude any claims based on this data. We therefore recommend making sufficient trials. Accompanying flooring manufacturer's instructions and the currently applicable codes must be observed. We gladly provide technical advice.

This Technical Information of 03.03.2009 supersedes all previous versions.